No. 216 Hopper Car



1. TP-SF00105

Hopper Brake Wheel (Brass)

TP-OF00030

Hopper Brake Wheel (Nickel)

- 2. TP-MS00074 Nut 4/40
- 3. Undefined
- TP-SF00042

Hopper Coal Pile 2 Per Car

- Undefined
- 6. TP-MS00010

Brakewheel (Brass) w/ Caps

TP-MS00011

Brakewheel (Nickel) w/ Caps

7. TP-SF00073

Brake Wheel Shaft (Nickel)

8. TP-SF00017

Brake Wheel Stanchion (Brass)

- 9. Undefined
- 10. Undefined
- 11. TP-MS00020

Coupler Long Shank w/Spring

- 12. TP-MS00026- Coupler Pin
- 13. TP-MS00025 Coupler Pocket
- 14. TP-SF00041

Hopper Door Assembly

- 15. Undefined
- 16. TP-SF00063 Truck w/o Pickup
- 17. TP-MS00041 Journal (Brass)

TP-MS00042 - Journal (Nickel) TP-MS00043 - Journal (Copper)

- 18. TP-SP00085 -Wheel
- 19. TP-SF00066 Truck Crossbrace
- 20. TP-SF00010 Axle

