

#334 Dispatch Board

Item Number 30-9022

The Rail King Operating Dispatch Board with its flipping boards lends realism to any passenger terminal. It is easy to wire and operate when you follow the operating instructions given.


To Wire the Board:

After positioning and mounting the dispatch board to your layout:

This dispatch board requires 14v of power to operate properly. When you first connect it and apply power the board will rotate through one cycle.

Operation:

To operate this board, press and release the activation button on the board to watch as the dispatchman travels across the board as the boards rotate, then stop with the latest travel information.



CAUTION: Electrically Operated Product:

Not recommended for children under 10 years of age. M.T.H. recommends adult supervision with children ages 10-16. As with all electric products, precautions should be observed during handling and use to reduce the risk of electric shock.

WARNING: When using electrical products, basic safety precautions should be followed including the following:

- Read instructions thoroughly before using this device.
- M.T.H. recommends that all users and persons supervising use examine the hobby transformer periodically for conditions that may result in the risk of fire, electric shock, or injury to persons, such as damage to the primary cord, plug blades, housing, output jack or other parts. In the event such conditions exist, the transformer should not be used until properly repaired.

As with all electrical appliances, this product should not be left in operation when unattended.

To obtain Warranty Service, please visit our website www.railking.com